

Mattress Assembly



Mattress Assembly

If you are missing any items listed on the following page, please e-mail Customer Service at customerservice@selectcomfort.com or call 1.800.472.7185

TROUBLESHOOTING

For answers to some common questions regarding your mattress, see the Frequently Asked Questions at the end of this section.

" This is the first time in three years that I slept through the entire night without getting up two or three times. I'm thrilled and amazed! Unbelievable! I wish we had purchased your sleeping system years ago."

- Keith Fisher, Jackson, MI

BEFORE YOU BEGIN

- ▶ Carefully check the contents of your mattress boxes

- ▶ **IMPORTANT NOTE** Prepare your foam pad(s)

If you purchased a bed with foam comfort pad(s), carefully open the pad(s) and set aside.

At least 30 minutes of expansion time is needed.

- ▶ **Orientation**

These instructions refer to "left" and "right" as if you are standing at the head of the bed looking toward the foot of the bed.

- ▶ **Using a Surge Protector**

While the Firmness Control™ System may be plugged directly into a wall outlet, we recommend using a surge protector to guard against unexpected power surges. We recommend using a surge protector that is listed to UL® 1449 with a clamping voltage of 330 volts, and a joule rating of 700 or higher.

Please note: Your 20-Year Limited Warranty does not cover damage to the Firmness Control™ System due to a power surge, regardless of the source. See the Limited Warranty on page 41 for more details.

CONTENTS

Carefully check the contents of your mattress boxes and compare with the list below. Each component is clearly labeled with the part name and part number.


QUANTITY

	Twin	Full/Queen Single Chamber	Dbl/Queen Dual Chamber	King
Mattress Cover Color and pattern will vary by model Shown as packaged 	1	1	1	1
Foam Border Walls Two long and two short Shown as packaged 	4	4	4	4
Corner Lock™ System Shown as packaged 	4	4	4	4
Air Chambers 	1	1	2	2
Firmness Control™ System with Remotes Remotes will vary 	1	1	1	1
Center Foam Wall Dual Chamber models only 	0	0	1	1
Foam Comfort Pad Color and pattern may vary Shown as packaged 	7000: 1 9000: 2	1 4	1 4	1 4

REMEMBER: Open the foam comfort pad(s) before you begin and let expand for 30 minutes.

1 POSITION MATTRESS COVER

Place on foundation or on existing bed platform.



Make sure the holes in the bottom of the cover are at the head of the bed.

2 UNZIP MATTRESS COVER

Set cover aside.




7000 and 9000 models have a double zipper — unzip lower zipper A and set top aside.

3 PLACE CORNER LOCKS


Place one in each corner.

Corner locks must go under the border wrap.




4 INSTALL FOAM BORDER WALLS

Place long border walls along sides.



5 INSTALL FOAM BORDER WALLS

Place short border walls at the head and foot.




Make sure the foam border walls are connected securely and squarely. The border wrap should cover the foam border walls.

6 INSTALL AIR CHAMBERS

Place air chambers so the hose connectors face the head of the bed, and lay on bottom when inflated.

Dual chambers shown




1 CONNECT FIRMNESS CONTROL™ SYSTEM

Place the Firmness Control™ System on the floor at the head of the bed and plug the power cord into the Firmness Control™ System and then into an electrical outlet.

Key Step:

Pass the two hoses marked "L" through the hole on the left side of the mattress cover and connect to the air chamber.

Press hose connections together until they click. Then complete the right side.



2 INFLATE AIR CHAMBER(S)

Using remote, inflate air chamber.

For dual chamber models, repeat for second air chamber.



Insert center foam wall between the two chambers.

Position the border wrap over foam border walls and air chambers as shown.

Press any button on the remote to activate.

For wireless remotes press L or R to activate and select a side.

Press the ▲ button several times to inflate to 20.




Important Notice: To ensure compliance with federal and state flammability requirements, the border wrap must be positioned correctly within the mattress as shown in the steps below.

9 INSTALL FOAM COMFORT PAD

Zip the Duvet cover onto the mattress (zipper A).


Unzip the top Duvet zipper (zipper B) and set aside.



Sleep Number® 7000 Bed

Carefully shake out pad.

Place the Intralux® Ultra comfort pad on top of the air chambers.




Make sure the patterned side is up. Then extend the border wrap over the foam comfort pad.

Sleep Number® 9000 Bed

Carefully shake out pads.

Place the blue memory foam on top for a more plush surface, or the white Intralux® Premium foam for a more firm surface.




Make sure to extend the border wrap over the foam comfort pad.

10 VERIFY BORDER WRAP POSITIONING


Verify that the border wrap extends over the Intralux® Ultra comfort pad.

Important Notice: To ensure compliance with federal and state flammability requirements, the border wrap must be positioned correctly within the mattress as shown in the steps below.



11 MATTRESS COVER

Zip the top of the mattress cover (zipper B).



Store air chamber caps inside mattress at head of bed.

Color and pattern may vary.

**YOU'RE DONE! NEXT STEP ►
THE FIRMNESS CONTROL™ SYSTEM**

LIMITED WARRANTY

What is covered:

- Select Comfort warrants that your mattress and/or foundation will be free from defects in materials and workmanship for a period of 20 years from the original purchase date.
- Warranty is limited to product repair or replacement only.

What is not covered:

- Conditions arising from normal wear and tear. (Conditions arising from normal wear and tear include, but are not limited to: mattress cover compression, foam compression, or discoloration of components.)
- Damage from tampering with any component or from opening the Firmness Control™ System.
- Damage from misuse or abuse of the warranted product or component.
- Damage from laundering or dry-cleaning.
- Acts of God, such as but not limited to lightning damage.

What you must do:

- Return the warranted product or component in sanitary condition to an authorized SELECT COMFORT® service center. Select Comfort will incur the cost of shipping up to two years after the original purchase date; after two years, the return shipping to Select Comfort will be at the customer's expense.
- Please telephone our Customer Service Department at 1.800.472.7185 to locate the nearest authorized service center and arrange for the return of the warranted product or component.

What we will do:

- Select Comfort, at its option, will repair or replace the defective product or component at a cost to the original purchaser based on the following table. The "price" is the price of the defective product or component at the time the warranty claim is made, or the price of a comparable product or component if the original product or component is no longer in production.

Years after purchase date	Original purchaser's cost
Up to 2 years	No Cost
2-20 years	20% plus 4% of price for each year from original purchase date.

- For example, if a warranty claim arises 12 years after the original purchase date, the cost to the original purchaser would be 68% of the price (that is, 20% plus 4% for each of the 12 years) and Select Comfort would be responsible for the remaining 32% of the price.

- Select Comfort reserves the right to substitute products or components of equal or better quality, and to use or deliver refurbished products or components in the repair or replacement of any product under this Limited Warranty.

What will void this warranty:

- Tampering with any component or opening the Firmness Control™ System and its hand control unit.
- Misuse or abuse of the warranted product or component.
- Sale, transfer or other disposal of the warranted product or component.

Limitations:

- Your exclusive remedy, IN LIEU OF ALL INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, INCLUDING FOR NEGLIGENCE, is limited to repair or replacement of any product or component deemed to be defective under the terms and conditions stated above. Select Comfort will bear no other damages or expenses.
- Customer maintains responsibility for installation of parts replaced under terms of the warranty.
- Select Comfort reserves the right to refuse to repair or replace any product or component that is returned in an unsanitary condition.
- This Limited Warranty applies only to the product as used in the United States and Canada. It is not applicable in U.S. territories or other countries.
- This Limited Warranty is non-transferable.
- Repair or replacement of a product or component under the terms of this Limited Warranty in no way lengthens the Limited Warranty period.
- ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS WRITTEN LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

All claims relating to the Limited Warranty of Select Comfort® products should be made by contacting Customer Service at 1.800.472.7185 or writing to Select Comfort Customer Service, 6105 Trenton Lane North, Minneapolis, MN 55442.

Foundation Assembly

If you are missing any items listed on the following page, please e-mail Customer Service at customerservice@selectcomfort.com or call 1.800.472.7185

TROUBLESHOOTING

For answers to some common questions regarding your foundation, see the Frequently Asked Questions at the end of this section.

" I assembled the Sleep Number bed by myself. My wife was in doubt at first, but, after sleeping one night, she said it was magic how well she slept without back pain. Now we sleep longer and more comfortably than on any previous mattress we've owned."

- C. Clark Shedd, Tucson, AZ

BEFORE YOU BEGIN

- ▶ Carefully check the contents of your foundation boxes
- ▶ Decide where to put your new bed
- ▶ Make sure there's an electric power source nearby for use with your Firmness Control[®] System
- ▶ Assemble your bed frame if you have one

Your foundation should be assembled directly onto your bed frame or on the floor. Some bed frames have slats that run from one side of the bed to the other. If your bed frame has slats, position the slats evenly to support the foundation. If your bed frame has fewer than three slats, we recommend adding additional slats to ensure adequate support for your foundation.

Caution: With some styles of bed frames, the foundation length may extend beyond the frame's support legs. This situation makes it possible for the frame to tip when significant weight is placed at the foot of the bed. Please use caution when sitting or placing weight on the foot of the bed when using these types of frames.

▶ King foundation

The King foundation consists of two Twins side by side. Complete the assembly of one unit, assemble the second, then place side by side on the bed frame.

Foundation Frequently Asked Questions

What if I can't get my center support beams flush with the side rails?

Make sure the letter on the center support beam matches the side rail. For example, the end of the center beam labeled "A" should connect to the side rail with the "A" on it. Additional force may be required.

How can I get my pins in all the way?

All pins are wider at one end and narrower at the other end. Make sure the "T" end is up and the narrow end goes into the side rail first. You may need to use a bit of force to get it in place.

What can I do if I can't get the deck panels to lay flat?

First, make sure all the pins and beams are flush. Then, set the deck panel over the notches. You should then be able to slide the panel into place.

Where is the hardware for the footboard and headboard brackets?

The same hardware for attaching the legs to the foundation is used for attaching the brackets. Align the bracket with the holes for the leg bolts. Attach the leg per the instructions.


If you still have questions or need assistance, look for answers on our Web site sleepnumber.com or please call Customer Service at 1.800.472.7185

CONTENTS

Carefully check the contents of your foundation boxes and compare with the list below. Each component is clearly labeled with the part name and part number.

QUANTITY

Twin	Full	Queen	King
------	------	-------	------



Side Rails

Texture and surface appearance may vary

2 each	2 each	2 each	4 each
--------	--------	--------	--------



Support /End Beams

Texture and surface appearance may vary

6	6	6	12
---	---	---	----



Deck Panels

Texture and surface appearance may vary

2	4	4	4
---	---	---	---



Pin Components

2	2	2	4
---	---	---	---



Fabric Coverlet

Packaged in the mattress box

Shown as packaged



1	1	1	1
---	---	---	---

Expanded Queen only



Corner Brackets

Packaged in the mattress box

0	0	4	0
---	---	---	---