



Your Remote and Its Functions

Single Chamber
(wakes when any button is pressed)



Dual Chamber
(wakes when L or R button is pressed)



Button	Function
Side (L) and (R)	Press to choose a side; it will display the previous SLEEP NUMBER® setting.
Firmer ▲ Softer ▼	Press and release the ▲ or ▼ button several times until desired Sleep Number setting is displayed. Adjustment will begin after a slight delay. The memory feature allows you to set your favorite Sleep Number setting into memory and recall it at any time. SETTING MEMORY - Press L or R to choose a side and wake up the remote - Adjust the bed to the Sleep Number setting you'd like as your memory setting - Press and hold the Memory button for 3 seconds - "Memory Set" will appear above the Sleep Number when it's set RECALLING MEMORY - Press L or R on the side you would like to recall - Press the Memory button 2 times within 5 seconds
Memory	The first press of the button will display the current Sleep Number set in memory. The second press of the button will adjust the bed to the memory setting. As the adjustment is taking place, the number displayed and tick marks will indicate the change.
Fill	The fill feature allows you to inflate one or both chambers to a Sleep Number setting of 100 - To fill both chambers press and hold the Fill button for at least 2 seconds - To fill one chamber press any button to wake up remote, then press L or R to select a side. Then press and hold Fill button for at least 2 seconds. To stop the fill feature at any time, press any button on the remote.

Firmness Control™ System

A 9-Volt battery is included and should last about six months under normal use. Replace the battery when the low battery indicator is displayed.

For more information on your remote see pages 26-27.