

OWNER'S MANUAL AND WARRANTY INFORMATION

The ~~EXCITING~~ New Generation in Bedding

Select Comfort[®]
CORPORATION

9301 - 75th Avenue North
Minneapolis, MN 55428

Select Comfort[®]
CORPORATION

IMPORTANT...READ THIS FIRST

You've just purchased the most remarkable mattress available today. Actually, it's more than just a mattress, it's a whole new, better way of sleeping. As you may know, whenever you buy a new mattress there is a transition period while your body adapts to your new bed. Some people are comfortable immediately; however, the usual adjustment period for any style bed is two weeks to a month.

During the adjustment period you may feel stiff and achy. This is normal; muscles that have stayed up all night supporting your spine are no longer stressed, while other muscles are adjusting to their proper supporting function.

Because Select Comfort's "touch of a button" comfort system is so unique, we have a recommended process to help you find your ideal comfort. Don't be surprised or discouraged if it takes some time for you to find the optimum firmness level; that's why we offer customers a 90 Night Trial program.

1. Before retiring for the evening, lay down and fully inflate your bed. You can feel when the air chamber is full; the motor does not shut off automatically. Just relax for a few minutes until your spine adjusts to the horizontal position.
 2. Touch the "Softer" button on your remote hand control, holding it down until it reaches a level that feels comfortable. You hear only a "click" when using the "Softer" button.) A small change in air pressure can have a significant change in the support level—and your comfort.
 3. Leave your Select Comfort mattress at this firmness level, with only minor adjustments, for several days.
 4. Experiment with changing the firmness in small increments, always staying at the same level for several days, until you find what makes you most comfortable. **Remember, every time you significantly change the inflation (firmness) level of your mattress, it's like getting used to a whole new bed!**
 5. If you feel stiffness in your neck and/or shoulders, you may want to try a flatter pillow.
 6. If you have any questions or problems, please call our Customer Service department at (800) 472-7185 and one of our sleep consultants will be happy to help you find your ideal comfort level!
- With the Select Comfort patented relief valve, you need not worry about overinflating your air chambers. The relief valve will automatically release air if too much pressure is exerted on your air chambers.
- Contained in this booklet are complete, easy-to-follow instructions for assembling your Select Comfort mattress. Before beginning, take a moment to read through them completely.
- At the back of this booklet, you'll find complete information on your warranty. Please fill out and mail in the enclosed registration card immediately, so that your warranty is properly activated.
- Now get ready to enjoy the best night's sleep you've ever experienced!

CONTENTS

List of components.....	2
Assembly instructions for standard mattress.....	3
Assembly instructions for horside waterbed replacement mattress.....	6
Troubleshooting - what to do if something is not right.....	10
What to do if you need warranty service.....	12
Warranty.....	13

REFERENCE GUIDE TO MATTRESS SIZES

Most people are not aware of the wide variety of styles and sizes available in mattresses today. As a result, when it's time to buy a new one, they often purchase a size that is really incorrect for them.

A good example is the full size, which for years has been the most popular size among many adult couples. In fact, the full size is 54" x75". That's actually the width of two crib mattresses and too short for a person stretched out whose height is 5'10" or more.

People of today are taller and bigger than their parents of only a generation ago. Therefore, it's important not only to choose the right mattress but the right size.


Here is a reference guide of the mattress sizes available today.

Traditional Mattress Sizes	Waterbed Sizes		
Twin	39"x75"	Super Single	48"x84"
Twin Long	39"x80"	Super Queen	60"x84"
Full	54"x75"	Super King	72"x84"
Queen	60"x80"		
Short Queen	60"x75"		
Eastern King	76"x80"		
California King	72"x84"		

LIST OF COMPONENTS

Traditional Mattress

- Mattress Cover (1)
- Center Foam Wall (1 for dual chamber only)
- Air Control Unit (1)
- Air Chambers (1 for single chamber)
(2 for dual chamber)
- Hand Controls (1 for single chamber)
(2 for dual chamber)
- White Plugs (1 for single chamber)
(2 for dual chamber)
- Hoses (1 for single chamber)
(2 for dual chamber)
- Attached to Chambers
- Clamps (1 for single chamber)
(2 for dual chamber)
- Foam Border Walls (2 long)
(2 short)




If Pillowtop

- Convuluted Pad (1)

Waterbed Mattress

- Hose Extender Kit (1)
- Mattress Cover (1)
- Center Foam Wall (1 for dual chamber only)
- Air Control Unit (1)
- Air Chambers (1 for single chamber)
(2 for dual chamber)
- Hand Controls (1 for single chamber)
(2 for dual chamber)
- White Plugs (1 for single chamber)
(2 for dual chamber)
- Hoses (1 for single chamber)
(2 for dual chamber)
- Attached to Chambers
- Clamps (2 for single chamber)
(4 for dual chamber)
- Elbows (1 for single chamber)
(2 for dual chamber)
- Riser Pads (8)
- If Pillowtop**
- Convuluted Pad (1)



ASSEMBLY INSTRUCTIONS FOR TRADITIONAL/PILLOWTOP STYLE MATTRESSES

TOOLS REQUIRED: One standard pliers.
BEFORE BEGINNING: Make sure that you have the boxes necessary for proper assembly. All boxes should be identified by the same initial in the colored square on the end of each box. If the boxes you received are not correct, contact Select Comfort at 1-800-472-7185 immediately.




Figure A

STEP ONE: Remove the cover and lay it quilted side down on a flat area large enough to assemble the entire mattress, a boxspring or bed platform works well. Next, completely unzip the underside of the mattress cover and fold back. (See Figure A.)





Figure B

STEP TWO: Remove the 4 foam border walls from the box. Place the two long walls down the length of the sides so the VELCRO® pads face inward and the zippers are face up. Place the two short walls at the head and foot, with zippers face up, making sure the VELCRO pads connect securely and squarely with the VELCRO on the other walls. Walls will bow out until mattress is fully inflated. (See Figure B below.)



Inset A




Figure C

(If Pillowtop): Pillowtop systems include a special convoluted foam pad for added comfort. The convoluted foam should be placed with the flat side down. It is inserted between the four foam border walls and pushed down so it is sitting firmly against the backing of the pillowtop and the four foam border walls. (See Inset A and Figure C.)

STEP THREE: (Dual Air Chamber Only): Couples who set their air chambers at different firmness levels sometimes feel a space between the two air chambers, while others never notice it. Since we want you to be happy with your Select Comfort mattress, we are enclosing an optional center foam wall for those of you who do feel this space. We recommend you initially put the bed together with this insert. Removing it at a later date will take very little time if you prefer not to use it. (See Figure D on next page.)

